

PROBLEM SYMPTOMS TABLE

Problem Symptom	Suspected Area	See Page
Rear window defogger system does not operate	<div>1. FL block assy</div> <div>•DEFOG H-fuse</div> <div>2. Engine room R/B</div> <div>•FR IG fuse</div> <div>3. Wire harness</div> <div>4. Engine room R/B No. 2</div> <div>•DEFOG relay</div> <div>5. Rear window defogger</div> <div>6. A/C control assembly</div>	<div>05-2130</div>