

DTC	C1787	ABSORBER CONTROL SWITCH CIRCUIT (TEST DIAGNOSIS)
-----	-------	---



CIRCUIT DESCRIPTION

The absorber control switch used is to select the attenuation modes of the shock absorber. 2 levels of attenuation, "SPORT" and "NORM", are available.

DTC No.	DTC Detecting Condition	Trouble Area
C1787	Absorber control switch signal does not change.	<ul style="list-style-type: none">• Absorber control switch• Absorber control switch circuit• Suspension control ECU

HINT:
DTC C1787 is output only in the test mode.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 INSPECT ABSORBER CONTROL SWITCH

Absorber Control Switch:

H F45839

- (a) Disconnect the absorber control switch connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Switch Condition	Tester Connection	Specified Condition
"SPORT"	2 (GND) - 4 (ECU1)	Below 1 Ω
"NORM"	2 (GND) - 4 (ECU1)	10 kΩ or higher

NG REPLACE ABSORBER CONTROL SWITCH

OK

2 CHECK HARNESS AND CONNECTOR (SUSPENSION CONTROL ECU - ABSORBER CONTROL SWITCH) (SEE PAGE 01-44)

Suspension Control ECU:

G25094 F44492

- (a) Disconnect the suspension control ECU A24 connector.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
A24-9 (SW1) - A21-4 (ECU1)	Below 1 Ω
A24-9 (SW1) - Body ground	10 kΩ or higher

Absorber Control Switch:


H F45878

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

3

CHECK HARNESS AND CONNECTOR (ABSORBER CONTROL SWITCH - BODY GROUND) (SEE PAGE 01-44)



(a) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
A21 - 2 (GND) - Body ground	Below Ω

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE SUSPENSION CONTROL ECU (SEE PAGE 25-20)