


## TERMINALS OF ECU

### 1. CHECK DRIVER DOOR ECU



- (a) Disconnect the D25 ECU connector.  
 (b) Check the voltage and resistance of each terminal of the wire harness side connector.

#### Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
GND (D25-1) – Body ground	W-B – Body ground	Ground	Constant	Below 1 Ω
CPUB (D25-4) – Body ground	V-Y – Body ground	+B (CPUB) power supply	Constant	10 to 14 V
SIG (D25-5) – Body ground	R-L – Body ground	+B (SIG) power supply	Ignition switch 1: OFF → 2: ON	1: Below 1 V → 2: 10 to 14 V
BDR (D25-6) – Body ground	R – Body ground	+B (BDR) power supply	Constant	10 to 14 V


If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the D25 ECU connector.  
 (d) Check the voltage of each terminal of the connectors.

#### Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
DSUP (D24-3) – DSE (D24-26)	L-W – L-O	Driver side adjustable anchor switch UP signal input	Driver side adjustable anchor switch 1: OFF → 2: UP → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V
DSDN (D24-14) – DSE (D24-25)	L-Y – L-O	Driver side adjustable anchor switch DOWN signal input	Driver side adjustable anchor switch 1: OFF → 2: DOWN → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V

## 2. CHECK PASSENGER DOOR ECU



- (a) Disconnect the F17 ECU connector.
- (b) Check the voltage and resistance of each terminal of the wire harness side connector.

### Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
GND (F17-1) – Body ground	W-B – Body ground	Ground	Constant	Below 1 $\Omega$
CPUB (F17-4) – Body ground	V-Y – Body ground	+B (CPUB) power supply	Constant	10 to 14 V
SIG (F17-5) – Body ground	R-L – Body ground	+B (SIG) power supply	Ignition switch 1: OFF → 2: ON	1: Below 1 V → 2: 10 to 14 V
BDR (F17-6) – Body ground	R – Body ground	+B (BDR) power supply	Constant	10 to 14 V

If the result is not as specified, there may be a malfunction on the wire harness side.


- (c) Reconnect the F17 ECU connector.
- (d) Check the voltage of each terminal of the connectors.

### Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
PSUP (F16-3) – PSE (F16-26)	R-B – BR-R	Passenger side adjustable anchor switch UP signal input	Passenger side adjustable anchor switch 1: OFF → 2: UP → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V
PSDN (F16-14) – PSE (F16-26)	R-Y – BR-R	Passenger side adjustable anchor switch DOWN signal input	Passenger side adjustable anchor switch 1: OFF → 2: DOWN → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V

If the result is not as specified, the ECU may have a malfunction.

### 3. LHD: CHECK DRIVER SIDE J/B (DRIVER SIDE J/B ECU)



- Disconnect the DG, DI J/B, D4 and D5 ECU connectors.
- Measure the voltage and resistance between each terminal of the wire harness side connectors and body ground.

#### Standard:


Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
MPX-B (D4-5) – Body ground	R-B – W-B	+B (MPX-B) power supply	Constant	10 to 14 V
MPX-IG (DI-2) – Body ground	L – Body ground	+B (MPX-IG) power supply	Ignition switch 1: OFF → 2: ON	1: Below 1 V → 2: 10 to 14 V
GND (DG-8) – Body ground	W-B – Body ground	Ground	Constant	Below 1 Ω
GND2 (D5-1) – Body ground	W-B – Body ground	Ground	Constant	Below 1 Ω

If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the DG, DI J/B, D4 and D5 ECU connectors.  
 (d) Measure the voltage between terminal of the connector and body ground.

**Standard:**


Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
DBM+ (D3-5) – Body ground	V – Body ground	Driver side anchor motor (+) drive signal output	Driver side adjustable anchor switch 1: OFF → 2: UP → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V
DBM– (D3-4) – Body ground	L – Body ground	Driver side anchor motor (–) drive signal output	Driver side adjustable anchor switch 1: OFF → 2: DOWN → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V
VC (D3-3) – E (D3-2)	L – W	Driver side anchor motor position sensor power source output	Ignition switch 1: OFF → 2: ON	1: Below 1 V → 2: 5 V
BES (D3-1) – E (D3-2)	Y – W	Driver side anchor motor position sensor pulse input	Driver side adjustable anchor switch 1: OFF → 2: UP/DOWN → 3: OFF	1: Below 1 V → 2: Pulse generation (see waveform 1) → 3: Below 1 V



- (e) Waveform 1:  
**Standard (Reference):**

Tester Connection	BES (D4-1) – E (D4-2)
Tool setting	2 V/DIV., 50 ms/DIV.
Vehicle condition	Switch operation

#### 4. LHD: CHECK PASSENGER SIDE J/B (PASSENGER SIDE J/B ECU)



- Disconnect the PE, PG J/B, and P4 ECU connectors.
- Measure the voltage and resistance between each terminal of the wire harness side connectors and body ground.

#### Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
MPX-B (PE-16) – Body ground	L-Y – Body ground	+B (MPX-B) power supply	Constant	10 to 14 V
MPX-IG (PE-3) – Body ground	R-L – Body ground	+B (MPX-IG) power supply	Ignition switch 1: OFF → 2: ON	1: Below 1 V → 2: 10 to 14 V
GND (PG-8) – Body ground	W-B – Body ground	Ground	Constant	Below 1 Ω
GND1 (P4-11) – Body ground	W-B – Body ground	Ground	Constant	Below 1 Ω


If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the PE, PG J/B, P4 ECU connectors.
- (d) Measure the voltage between terminal of the connector and body ground.

**Standard:**

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
PBM+ (P5-3) – Body ground	SB – Body ground	Passenger side anchor motor (+) drive signal output	Passenger side adjustable anchor switch 1: OFF → 2: UP → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V
PBM– (P5-4) – Body ground	Y – Body ground	Passenger side anchor motor (–) drive signal output	Passenger side adjustable anchor switch 1: OFF → 2: DOWN → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V

5. RHD:  
CHECK DRIVER SIDE J/B (DRIVER SIDE J/B ECU)



- Disconnect the DI, DG J/B, and D4 ECU connectors.
- Measure the voltage and resistance between each terminal of the wire harness side connectors and body ground.

**Standard:**


Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
MPX-B (D4-1) - Body ground	R-B - Body ground	+B (MPX-B) power supply	Constant	10 to 14 V
MPX-IG (DI-10) - Body ground	L - Body ground	+B (MPX-IG) power supply	Ignition switch 1: OFF → 2: ON	1: Below 1 V → 2: 10 to 14 V
GND (DG-7) - Body ground	W-B - Body ground	Ground	Constant	Below 1 Ω
GND2 (D4-5) - Body ground	W-B - Body ground	Ground	Constant	Below 1 Ω

If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the DI, DG J/B, D4 ECU connectors.  
 (d) Measure the voltage between terminal of the connector and body ground.

**Standard:**

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
DBM+ (D3-1) – Body ground	V – Body ground	Driver side anchor motor (+) drive signal output	Driver side adjustable anchor switch 1: OFF → 2: UP → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V
DBM- (D3-2) – Body ground	L – Body ground	Driver side anchor motor (-) drive signal output	Driver side adjustable anchor switch 1: OFF → 2: DOWN → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V
VC (D3-3) – E (D3-5)	Y – W	Driver side anchor motor position sensor power source output	Ignition switch 1: OFF → 2: ON	1: Below 1 V → 2: 5 V
BES (D3-4) – E (D3-5)	Y – W	Driver side anchor motor position sensor pulse input	Driver side adjustable anchor switch 1: OFF → 2: UP/DOWN → 3: OFF	1: Below 1 V → 2: Pulse generation (see waveform 1) → 3: Below 1 V




- (e) Waveform 1:  
**Standard (Reference):**

Tester Connection	BES (D4-1) – E (D4-2)
Tool setting	2 V/DIV., 50 ms/DIV.
Vehicle condition	Switch operation



6. RHD:  
CHECK PASSENGER SIDE J/B (PASSENGER SIDE J/B ECU)



- (a) Disconnect the PE, PG J/B, P4 ECU connectors.  
(b) Measure the voltage and resistance between each terminal of the wire harness side connectors and body ground.

**Standard:**

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
MPX-B (PE-16) – Body ground	L-Y – Body ground	+B (MPX-B) power supply	Constant	10 to 14 V
MPX-IG (PE-7) – Body ground	R-L – Body ground	+B (MPX-IG) power supply	Ignition switch 1: OFF → 2: ON	1: Below 1 V → 2: 10 to 14 V
GND (PG-7) – Body ground	W-B – Body ground	Ground	Constant	Below 1 Ω
GND1 (P4-1) – Body ground	W-B – Body ground	Ground	Constant	Below 1 Ω

If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the PE, PG J/B, P4 ECU connectors.
- (d) Measure the voltage between terminal of the connector and body ground.

**Standard:**

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
PBM+ (P5-3) – Body ground	L – Body ground	Passenger side anchor motor (+) drive signal output	Passenger side adjustable anchor switch 1: OFF → 2: UP → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V
PBM– (P5-2) – Body ground	Y – Body ground	Passenger side anchor motor (–) drive signal output	Passenger side adjustable anchor switch 1: OFF → 2: DOWN → 3: OFF	1: Below 1 V → 2: 10 to 14 V → 3: Below 1 V