

DTC	P0031	OXYGEN SENSOR HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 1)
DTC	P0032	OXYGEN SENSOR HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 1)
DTC	P0037	OXYGEN SENSOR HEATER CONTROL CIRCUIT LOW (BANK 1 SENSOR 2)
DTC	P0038	OXYGEN SENSOR HEATER CONTROL CIRCUIT HIGH (BANK 1 SENSOR 2)
DTC	P0051	OXYGEN SENSOR HEATER CONTROL CIRCUIT LOW (BANK 2 SENSOR 1)
DTC	P0052	OXYGEN SENSOR HEATER CONTROL CIRCUIT HIGH (BANK 2 SENSOR 1)
DTC	P0057	OXYGEN SENSOR HEATER CONTROL CIRCUIT LOW (BANK 2 SENSOR 2)
DTC	P0058	OXYGEN SENSOR HEATER CONTROL CIRCUIT HIGH (BANK 2 SENSOR 2)

HINT:

- Bank 1 refers to the bank that includes cylinder No. 1.
- Bank 2 refers to the bank that does not include cylinder No. 1.
- Cylinder No. 1 is located in the front part of the engine, opposite the transmission.
- Sensor 1 refers to the sensor closest to the engine body.
- Sensor 2 refers to the sensor farthest away from the engine body.

The Heated Oxygen Sensor (HO2S) is used to monitor oxygen concentration in the exhaust gas. For optimum catalytic converter operation, the air–fuel mixture must be maintained near the ideal stoichiometric ratio. The HO2S output voltage changes suddenly in the vicinity of the stoichiometric ratio. The ECM adjusts the fuel injection time so that the air–fuel ratio is nearly stoichiometric.

If oxygen is not in the exhaust gas, the air-fuel ratio is RICH. The HO2S voltage increases above 0.45 V and the HO2S informs the ECM of the RICH condition.



The ECM provides a pulse width modulated control circuit to adjust current through the heater. The HO2S heater circuit uses a relay on the +B side of the circuit.

The diagram shows the following components and connections:

- From Battery:** Connected to the **EFI NO.1 Fuse**.
- EFI MAIN Relay:** A relay with a coil connected to ground and a switch controlled by the battery through the fuse.
- HO2S (Heater and Sensor):**
 - +B:** Connected to the battery through the EFI MAIN Relay switch.
 - E1:** Connected to ground.
 - Heater:** Represented by a resistor symbol.
 - Sensor:** Represented by a square symbol.
- ECM (Engine Control Module):**
 - HT1A:** Connected to the HO2S Heater.
 - OX1A:** Connected to the HO2S Sensor.
 - O1A-:** Connected to ground.
 - MREL:** Connected to the EFI MAIN Relay coil.
- Duty Control:** A pulse-width modulated (PWM) signal connected to the ECM via a resistor.

A87980

DTC No.	DTC Detection Condition	Trouble Area
P0031 P0037 P0051 P0057	HO2S heater current is below 0.25 A when heater operates with +B greater than 11.5 V (1 trip detection logic)	<ul style="list-style-type: none"> • Open or short in HO2S heater circuit • HO2S heater • EFI MAIN relay • ECM
P0032 P0038 P0052 P0058	HO2S heater current exceeds 2 A when heater operates (1 trip detection logic)	<ul style="list-style-type: none"> • Open or short in HO2S heater circuit • HO2S heater • EFI MAIN relay • ECM

MONITOR DESCRIPTION

The sensing portion of the HO₂S has a zirconia element which is used to detect oxygen concentration in the exhaust. If the zirconia element is at the proper temperature and difference of the oxygen concentration between the inside and outside surface of the sensor is large, the zirconia element will generate voltage signals. In order to increase the oxygen concentration detecting capacity in the zirconia element, the ECM supplements the heat from the exhaust with heat from a heating element inside the sensor. When current in the HO₂S heater is out of the standard operating range, the ECM interprets this as a fault in the HO₂S heater. The ECM illuminates the MIL and sets a DTC.

Normally, the HO₂S heater current is 0.4 to 1.0 A.

Example:

The ECM will set a high current DTC if the current in the sensor is more than 2 A. Similarly, the ECM will set a low current DTC if the current is less than 0.25 A.

The monitor runs if the engine is started and run at idle for 9 minutes or more.

LHD



Y




INSPECTION PROCEDURE

HINT:

Read freeze frame data using the Intelligent Tester II. Freeze frame data records the engine conditions when a malfunction is detected. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, and other data from the time the malfunction occurred.

1 INSPECT HEATED OXYGEN SENSOR (HT1A, HT2A, HT1B, HT2B VOLTAGE)



- Disconnect the H9, H10, H19 or H20 HO2S connector.
- Measure the resistance between the terminals of the HO2S connector.

Standard:


Tester Connection	Specified Condition
H9-1 (HT) - H9-2 (+B)	5 to 10 Ω at 20°C (68°F)
H9-1 (HT) - H9-4 (E1)	10 k Ω or higher
H10-1 (HT) - H10-2 (+B)	5 to 10 Ω at 20°C (68°F)
H10-1 (HT) - H10-4 (E1)	10 k Ω or higher
H19-2 (HT) - H19-1 (+B)	5 to 10 Ω at 20°C (68°F)
H19-2 (HT) - H19-3 (E1)	10 k Ω or higher
H20-2 (HT) - H20-1 (+B)	5 to 10 Ω at 20°C (68°F)
H20-2 (HT) - H20-3 (E1)	10 k Ω or higher

NG

REPLACE HEATED OXYGEN SENSOR

OK

2 INSPECT EFI MAIN RELAY (HEATER RESISTANCE)



- Remove the EFI MAIN relay from the engine room R/B.
- Measure the resistance of the EFI MAIN relay.

Standard:


Tester Connection	Specified Condition
3 - 5	10 k Ω or higher
3 - 5	Below 1 Ω (apply battery voltage to terminals 1 and 2)

NG

REPLACE EFI MAIN RELAY

OK

3 INSPECT ECM (HT1A, HT2A, HT1B, HT2B) VOLTAGE



- (a) Turn the ignition switch ON.
 (b) Measure the voltage of the ECM.

Standard:

Tester Connection	Specified Condition
E6-24 (HT1A) - E7-7 (E1)	9 to 14 V
E5-5 (HT2A) - E7-7 (E1)	9 to 14 V
E3-2 (HT1B) - E7-7 (E1)	9 to 14 V
E3-1 (HT2B) - E7-7 (E1)	9 to 14 V

OK


REPLACE ECM (See page 10-21)

NG

4 CHECK WIRE HARNESS (ENGINE ROOM R/B - HO2S - ECM AND GROUND)

Wire Harness Side

H9 Bank 1 Sensor 1 H19 Bank 1 Sensor 2
 H10 Bank 2 Sensor 1 H20 Bank 2 Sensor 2




Heated Oxygen Sensor


A55009

- (a) Check the wire harness between the ECM and HO2S.
 (1) Disconnect the H9, H10, H19 or H20 HO2S connector.
 (2) Disconnect the E3, E5 or E6 ECM connector.
 (3) Measure the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
H9-1 (HTL) - E6-24 (HT1A)	Below 1 Ω
H10-1 (HTR) - E5-5 (HT2A)	Below 1 Ω
H19-2 (HT) - E3-2 (HT1B)	Below 1 Ω
H20-2 (HT) - E3-1 (HT2B)	Below 1 Ω
H9-1 (HTL) or E6-24 (HT1A) - Body ground	10 k Ω or higher
H10-1 (HTR) or E5-5 (HT2A) - Body ground	10 k Ω or higher
H19-2 (HT) or E3-2 (HT1B) - Body ground	10 k Ω or higher
H20-2 (HT) or E3-1 (HT1B) - Body ground	10 k Ω or higher





- (b) Check the wire harness between the HO2S and EFI MAIN relay.
- (1) Disconnect the H9, H10, H19 or H20 HO2S connector.
 - (2) Remove the EFI MAIN relay from the Engine Room R/B.
 - (3) Measure the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
H9-2 - R/B EFI MAIN relay terminal 3	Below 1 Ω
H10-2(+B) - R/B EFI MAIN relay terminal 3	Below 1 Ω
H19-1(+B) - R/B EFI MAIN relay terminal 3	Below 1 Ω
H20-1(+B) - R/B EFI MAIN relay terminal 3	Below 1 Ω
H9-2(+B) - Body ground	10 k Ω or higher
H10-2(+B) - Body ground	10 k Ω or higher
H19-2(+B) - Body ground	10 k Ω or higher
H20-2(+B) - Body ground	10 k Ω or higher

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

REPLACE ECM (See page 10-21)