


TERMINALS OF ECU

1. CHECK SEAT BELT CONTROL ECU



- (a) Disconnect the S65 ECU connector.
 (b) Measure the voltage and resistance of the wire harness side connector.

Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
+B-9 (S65) – S65-18 (PGND)	B – W-B	Seat belt control ECU power source line	Always	10 to 14 V
PGND (S65-18) – Body ground	W-B – Body ground	Seat belt control ECU ground line	Always	Below 1 Ω

If the result is not as specified, there may be a malfunction on the wire harness side.

- (c) Reconnect the S65 ECU connector.
 (d) Measure the voltage and resistance of the connector.

Standard:

Symbols (Terminal No.)	Wiring Color	Terminal Description	Condition	Specified Condition
MOR+ (S65-1) – PGND (S65-18)	R – W-B	Seat belt motor RH power source line	Ignition switch ON	4.0 to 8.5 V
MOL+ (S65-2) – PGND (S65-18)	W – W-B	Seat belt motor LH power source line	Ignition switch ON	4.0 to 8.5 V
IG1 (S65-3) – Body ground	GR – Body ground	Seat belt control ECU power source line	Ignition switch ON	10 to 14 V
CANH (S65-4) – Body ground	–	CAN communication	Engine idling	Pulse generation
CANL (S65-6) – Body ground	–	CAN communication	Engine idling	Pulse generation
SIL (S65-7)	Y	Diagnosis check	Check if communication is available using a intelligent tester II	Communication is available
MOR- (S65-10) – Body ground	G – Body ground	Seat belt motor RH ground line	Ignition switch ON	4.0 to 8.5 V
MOL- (S65-11) – Body ground	L – Body ground	Seat belt motor LH ground line	Ignition switch ON	4.0 to 8.5 V

If the result is not as specified, the ECU may have a malfunction.