

PROBLEM SYMPTOMS TABLE

HINT:

Proceed to the troubleshooting for each circuit in the table below.

Symptom	Suspected Area	See page
• When the ignition switch is in the ON position, the SRS warning light sometimes comes on after approximately 6 seconds.	• SRS warning light circuit malfunction (Always lights up, when DTC is not output).	05-1272
• SRS warning light always comes on even when DTC is not output.	• SRS warning light circuit malfunction (Always lights up, when DTC is not output).	05-1272
• With the ignition switch is in the ON position, the SRS warning light does not come on.	• SRS warning light circuit malfunction (Does not light up, when ignition switch is turned to the ON position).	05-1276
• SRS warning light is blink.	• Diagnosis circuit	05-1278
• DTC cannot read.	• Diagnosis circuit	05-1278