

INSPECTION

1. Vehicles not involved in collision:

INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Do a diagnostic system check (See page DI-1).

2. Vehicle involved in collision and airbag is not deployed:

INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Do a diagnostic system check (See page DI-1).

3. Vehicle involved in collision and airbag is deployed:

Replace the seat position sensor assembly (See page RS-57).