

## DIAGNOSTIC TROUBLE CODE CHART

### HINT:

If a trouble code is displayed during the DTC check, check the circuit listed for that code. For details of each code, refer to the "See page" under respective "DTC No." in the DTC chart.

DTC No. (See Page)	Circuit Inspection	Trouble Area
P0500 (05-3600)	Vehicle Speed Sensor Circuit Malfunction	<ul style="list-style-type: none"> <li>• Vehicle speed sensor</li> <li>• Vehicle speed sensor signal circuit</li> <li>• ECM</li> </ul>
P0503 (05-3600)	Vehicle Speed Sensor Circuit Malfunction	<ul style="list-style-type: none"> <li>• Vehicle speed sensor</li> <li>• Vehicle speed sensor circuit</li> <li>• ECM</li> </ul>
P0571 (05-3601)	Stop Light Switch Circuit Malfunction	<ul style="list-style-type: none"> <li>• Stop lamp switch assy</li> <li>• Stop lamp switch assy circuit</li> <li>• Driver side J/B ECU</li> <li>• ECM</li> </ul>
P0607 (05-3609)	Input Signal Circuit Malfunction	<ul style="list-style-type: none"> <li>• ECM</li> </ul>