





## Stereo Component Amplifier



INSPECTION PROCEDURE

1 INSPECT STEREO COMPONENT AMPLIFIER ASSY(+B, +B2, ACC, GND, E)



- (a) Disconnect the stereo component amplifier assy connector S33, S34.
- (b) Measure the resistance according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
GND - Body ground	Always	Below 1 Ω
E - Body ground	Always	Below 1 Ω

- (c) Measure the voltage according to the value(s) in the table below.

**Standard:**

Tester connection	Condition	Specified condition
B+, B+*2 - GND	Always	10 to 14 V
+B2*1 - GND	Always	10 to 14 V
ACC - GND	Ignition SW ACC	10 to 14 V

\*1: Standard Models:

\*2: Mark Levinson Models:

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN DIAGNOSTIC TROUBLE CODE CHART (SEE PAGE 05-1788)