

DTC	U0126	COMMUNICATION ERROR OF STEERING SENSOR
------------	--------------	---

CIRCUIT DESCRIPTION

This circuit detects the angle and direction of the steering and automatically transmits a signal to the skid control ECU and cruise control ECU (distance control ECU).

DTC No.	DTC Detection Condition	Trouble Area
U0126	While dynamic radar cruise control is either preparing for operation or operating, ECM continuously receives steering sensor malfunction signal for certain amount of time	<ul style="list-style-type: none"> • Communication circuit • Steering sensor • Cruise control ECU (Distance control ECU) • ECM

INSPECTION PROCEDURE

HINT:

This circuit uses CAN communication. Therefore, if there are any malfunctions in the communication circuit, one or more DTCs in the CAN communication system will be output.

Go to CAN COMMUNICATION SYSTEM (See Pub. No. RM1049E, page 05-3306)