

<b>DTC</b>	<b>P0604</b>	<b>INTERNAL CONTROL MODULE RANDOM ACCESS MEMORY (RAM) ERROR</b>
<b>DTC</b>	<b>P0606</b>	<b>ECM/PCM PROCESSOR</b>
<b>DTC</b>	<b>P0607</b>	<b>CONTROL MODULE PERFORMANCE</b>
<b>DTC</b>	<b>P0657</b>	<b>ACTUATOR SUPPLY VOLTAGE CIRCUIT/OPEN</b>

## CIRCUIT DESCRIPTION

The ECM continuously monitors its internal memory status, internal circuits, and output signals sent to the throttle actuator. This self-check insures that the ECM is functioning properly. If any malfunction is detected, the ECM will set the appropriate DTC and illuminate the MIL.

The ECM memory status is diagnosed by internal "mirroring" of the main CPU and the sub CPU to detect Random Access Memory (RAM) errors. The two CPUs also perform continuous mutual monitoring. The ECM illuminates the MIL and set a DTC if: 1) outputs from the two CPUs are different and deviate from the standards, 2) the signals sent to the throttle actuator deviate from the standards, 3) a malfunction is found in the throttle actuator supply voltage, and 4) any other ECM malfunction is found.

DTC No.	DTC Detection Condition	Trouble Area
P0604 P0606 P0607 P0657	ECM internal error	ECM

## INSPECTION PROCEDURE

**REPLACE ECM (See page 10-21)**