


DTC	B1428	REAR SOLAR SENSOR CIRCUIT
-----	-------	---------------------------


CIRCUIT DESCRIPTION



A photodiode in the A/C solar sensor detects solar radiation and sends signals to the A/C amplifier.

DTC No.	Detection Item	Trouble Area
B1428	Rear solar sensor circuit (Rear side) (Open or short)	<ul style="list-style-type: none">• A/C solar sensor (Rear solar sensor)• Harness or connector between A/C solar sensor (Rear solar sensor) and A/C amplifier• A/C amplifier

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE ON INTELLIGENT TESTER

- (a) Connect the Intelligent Tester II to the DLC3.
- (b) Turn the Ignition switch to the ON position and push the Intelligent Tester II main switch on.
- (c) Select the item below in the DATA LIST, and read the display on the Intelligent Tester II.

DATA LIST / AIR CONDITIONER:

Item	Measure Item/Display (Range)	Normal Condition	Diagnostic Note
Rear Solar Sensor (Rear Solar Sens)	Rear Solar Sensor min.: 0 max.: 255	Changes depending on brightness	-

OK:
The display is as specified in the normal condition.

Result:

NG	A
OK (Checking from the PROBLEM SYMPTOM TABLE)	B
OK (Checking from the DTC)	C

B


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-778)

C

REPLACE AIR CONDITIONING AMPLIFIER (SEE PAGE 55-16)

A

2 INSPECT AIR CONDITIONING AMPLIFIER (TSRr - GND)



- (a) Remove the A/C amplifier with connector still connected.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
A14-30 (TSRr) - A15-16 (S5-4)	Sensor is subjected to electric light	0.8 to 4.3 V
A14-30 (TSRr) - A15-16 (S5-4)	Sensor is covered by a cloth	Below 0.8 V

HINT:

- As the temperature increases, the voltage decreases.
- Use an incandescent lamp for inspection. Bring it within 30 cm (11.8 in.) of the solar sensor.

Result:

NG	A
OK (Checking from the PROBLEM SYMPTOMS TABLE)	B
OK (Checking from the DTC)	C

B

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 05-778)


C

REPLACE AIR CONDITIONING AMPLIFIER (SEE PAGE 55-16)

A

3 INSPECT A/C SOLAR SENSOR

A/C Solar Sensor
Connector
Front View:



E50667

E72857

- (a) Remove the A/C solar sensor.
- (b) Measure the resistance according to the value(s) in the table below.
- (c) Connect the positive (+) lead from the ohmmeter to terminal 1 and negative (-) lead to terminal 2 of the A/C solar sensor.

Standard:

Tester connection	Condition	Specified condition
A32-1 - A32-2	Sensor is subjected to electric light	Except $\infty \Omega$
A32-1 - A32-2	Sensor is covered by a cloth	$\infty \Omega$ (No continuity)

NOTICE:

The connection procedure for using a digital tester such as a TOYOTA electrical tester is shown above. When using an analog tester, connect the positive (+) lead to terminal 2 and negative (-) lead to terminal 1 of the solar sensor.

HINT:

- As the inspection light is moved away from the sensor, the voltage increases.
- Use an incandescent lamp for inspection. Bring it within 30 cm (11.8 in.) of the solar sensor.


NG

REPLACE A/C SOLAR SENSOR

OK

4

CHECK HARNESS AND CONNECTOR (A/C SOLAR SENSOR - AIR CONDITIONING AMPLIFIER) (SEE PAGE 01-44)



(a) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
A14-30 (TSRR) - A32-2	Always	Below 1 Ω
A15-16 (S5-4) - A32-1	Always	Below 1 Ω
A14-30 (TSRR) - Body Ground	Always	10 kΩ or higher
A15-16 (S5-4) - Body Ground	Always	10 kΩ or higher

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE AIR CONDITIONING AMPLIFIER (SEE PAGE 55-16)