

## REPLACEMENT

### 1. REMOVE V-BANK COVER

- (a) Remove the 2 nuts and V-bank cover.

### 2. REMOVE CAMSHAFT TIMING OIL CONTROL VALVE ASSY LH

- (a) Disconnect the oil control valve connector.
- (b) Remove the bolts and oil control valve.

### 3. INSTALL CAMSHAFT TIMING OIL CONTROL VALVE ASSY LH

- (a) Install the oil control valve with the bolt.

**Torque: 7.5 N·m (76.5 kgf·cm, 66 in·lbf)**

- (b) Connect the oil control valve connector.

### 4. INSTALL V-BANK COVER

**Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)**