



HEIGHT CONTROL INDICATOR LAMP CIRCUIT

CIRCUIT DESCRIPTION

The vehicle height is controlled by pressing the "HIGH" button of the height control switch, "Height Hi" is displayed on the multi-information display.


WIRING DIAGRAM





INSPECTION PROCEDURE


1 CHECK HARNESS AND CONNECTOR (SUSPENSION CONTROL ECU - COMBINATION METER ASSY) (SEE PAGE 01-44)



- (a) Disconnect the suspension control ECU A24 connector.
(b) Disconnect the combination meter assy C12 connector.
(c) Measure the resistance according to the value(s) in the table below.

Standard:


Tester Connection	Specified Condition
A24-19(VH) - C12-17	Below 1 Ω
A24-19(VH) - Body ground	10 kΩ or higher



NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

2 CHECK HARNESS AND CONNECTOR (COMBINATION METER ASSY - BODY GROUND) (SEE PAGE 01-44)



- (a) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Specified Condition
C12-11 - Body ground	Below 1 Ω

NG REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (SEE PAGE 05-241)