


**LHD Models**

The diagram illustrates the electrical system for LHD models, featuring the following components and connections:

- Battery:** Connected to the B-L line.
- Passenger Side J/B:** Contains terminals PA, PJ, PB, PI, PE, and PI. It interfaces with the B-R, R-L, G, V, and R lines.
- Driver Side J/B:** Includes a D-IG1 Relay, MPX-IG, AM1, DA, DF, DG, and DE. It connects to the R-L, R-W, W-B, and W-L lines.
- FL Block Assy:** Features P-J/B, D/C CUT, ALT, and D-J/B sections, interfacing with B-L and B-W lines.
- Rear Door RH ECU:** Controls BDR, CPUB, SIG, and GND through R16 relays.
- Relays and Switches:** BB1, BB2, I17 (Ignition Switch), J14, J13, J14, and AJ27 are shown with their respective terminal configurations.
- Grounding:** Multiple ground points are indicated for IG, IR, BN, and BO.

## RHD Models



## INSPECTION PROCEDURE

## 1 INSPECT FUSE (RR DOOR RH, MPX-B1, MPX-IG, AM1, D/C CUT)

- (a) Remove the RR DOOR RH and MPX-B1 fuses from the passenger side J/B.  
 (b) Remove the MPX-IG and AM1 fuses from the driver side J/B.  
 (c) Remove the D/C CUT fuse from the FL block.  
 (d) Measure the resistance.


Standard: Below 1  $\Omega$

NG

REPLACE FUSE

OK

## 2 INSPECT RELAY (D-IG1)



- (a) Remove the D-IG1 relay from the driver side J/B.  
 (b) Check the resistance.

Standard:


Tester Connection	Specified Condition
3 - 5	10k $\Omega$ or higher
3 - 5	Below 1 $\Omega$ (when battery voltage is applied to terminals 1 and 2)

NG

REPLACE RELAY

OK

## 3 CHECK WIRE HARNESS (REAR DOOR RH ECU - BODY GROUND)



- (a) Disconnect the R16 ECU connector.  
 (b) Measure the voltage and resistance of the wire harness side connector.

Standard:

Tester Connection	Condition	Specified Condition
R16-1 (CPUB) - Body Ground	Constant	10 to 14 V
R16-2 (BDR) - Body Ground	Constant	10 to 14 V
R16-26 (SIG) - Body Ground	Ignition switch OFF $\rightarrow$ ON	0 V $\rightarrow$ 19 to 14 V
R16-6 (GND) - Body Ground	Constant	Below 1 $\Omega$

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2340)