

CRUISE CONTROL SYSTEM

8204M-01

PRECAUTION

NOTICE:

- When the negative (-) battery terminal is disconnected, initialize the following systems after the terminal is reconnected.

System Name	See page
Power Window Control System	01-20
Front Power Seat Control System	01-20
Back Guide Monitor System	01-20

- When the ECM or cruise control ECU (distance control ECU) has been replaced, it is necessary to make the ECM recognize spec information (whether the vehicle is equipped with the dynamic laser or not). For procedures, refer to 82-2.