

DTC CHECK/CLEAR

1. DTC CHECK

(a) Check the DTCs.

- (1) Prepare the Intelligent Tester II.
- (2) Connect the Intelligent Tester II to the DLC3 at the lower part of the instrument panel.
- (3) Turn the ignition switch to the ON position and turn the Intelligent Tester II on.
- (4) Use the Intelligent Tester II to check the DTCs and the freeze frame data, and note or print the result (see the operator's manual for operating instructions).
- (5) See [page 05-695](#) to confirm the details of the DTCs.

2. DTC CLEAR

(a) Clear the DTCs.

- (1) The following procedures clear the DTCs and freeze frame data.
 - When using the Intelligent Tester II:
See the operator's manual for instructions to clear the DTCs.

HINT:

Disconnect the battery negative terminal cable will clear DTCs.

In this case, initialization is required (see [page 05-678](#)).