

## PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Mirror does not operate	1. D DOOR fuse 2. P DOOR fuse 3. D ACC fuse 4. Outer mirror switch assy 5. Outer rear view mirror assy 6. Seat memory switch (driver side only) 7. Wire harness	<a href="#">70-29</a> <a href="#">70-29</a> <a href="#">70-29</a> <a href="#">70-39</a> <a href="#">70-39</a> <a href="#">70-39</a> –
Mirror operates abnormally	1. D DOOR fuse 2. P DOOR fuse 3. D ACC fuse 4. Outer mirror switch assy 5. Outer rear view mirror assy 6. Seat memory switch (driver side only) 7. Wire harness	<a href="#">70-29</a> <a href="#">70-29</a> <a href="#">70-29</a> <a href="#">70-39</a> <a href="#">70-39</a> <a href="#">70-39</a> –
Reverse-shift-linked operation of mirrors does not work.	1. Outer rear view mirror assy 2. PNP switch 3. Wire harness	<a href="#">70-39</a> <a href="#">05-563</a> –

### HINT:

The power mirror control system is part of the large-scale multiplex communication system. This system features shared communication wiring that reduces the wiring complexity of the communication lines. The first step in any repair is to confirm the proper operation of the communication system. Proceed with troubleshooting after the communication has been verified (see the Multiplex Communication System).