

FAIL-SAFE CHART

If the television camera ECU detects a malfunction, the fail safe functions shown in the table below are activated.

Malfunction parts	Detecting condition	Function "Manual Assist Mode"	Function "Serial Parking Assist Mode"
Steering angle sensor	<ul style="list-style-type: none"> • Transmission of sensor malfunction signal • Open circuit in sensor signal • Communication malfunction between the steering angle sensor and television camera ECU 	–	Switches to the "Manual Assist Mode" automatically
Steering angle sensor	<ul style="list-style-type: none"> • Transmission neutral steering point correction incomplete signal 	–	Displays "System initializing"
Television camera assy	<ul style="list-style-type: none"> • Transmission of television camera malfunction signal 	Stops signal reception and displays a dark screen	Stops signal reception and displays a dark screen
Television camera ECU	<ul style="list-style-type: none"> • Malfunction of television camera ECU unit 	Stops system operation	Stops system operation
Navigation ECU	<ul style="list-style-type: none"> • No response from navigation ECU • Transmission of navigation ECU malfunction signal 	–	Switches to the "Manual Assist Mode" automatically