

① : Engine Room No.1 R/B

○ : Engine Room No.1 J/B

Engine Compartment Left (See Page 8)

* 1:H-LP R LWR

* 2:H-LP L LWR

