

## TILT AND TELESCOPIC MANUAL SWITCH CIRCUIT

### CIRCUIT DESCRIPTION

The signals generated by operating the manual switch are sent to the multiplex tilt & telescopic ECU through the light control communication bus.

### WIRING DIAGRAM

See page 05-3212.

### INSPECTION PROCEDURE

#### 1 READ VALUE ON INTELLIGENT TESTER

- Connect the intelligent tester to the DLC3.
- Turn the ignition switch to the ON position and turn the intelligent tester on.
- Select the DATA LIST (Combination switch ECU) on the intelligent tester.
- Check the tilt and telescopic manual switch.

Item	Measurement Item/ Range (Display)	Normal Condition	Diagnostic Note
Telesco Short Switch	Telesco SHORT switch status/ OFF or ON	OFF: Telescopie short is not activated by manual switch ON: Telescopie short is activated by manual switch	—
Telesco Long Switch	Telesco LONG switch status/OFF or ON	OFF: Telescopie long is not activated by manual switch ON: Telescopie long is activated by manual switch	—
Tilt Down Switch	Tilt DOWN switch/OFF or ON	OFF: Tilt down is not activated by manual switch ON: Tilt down is activated by manual switch	—
Tilt Up Switch	Tilt UP switch/OFF or ON	OFF: Tilt up is not activated by manual switch ON: Tilt up is activated by manual switch	—

OK:

"ON" is displayed on the tester screen when each switch is turned on.

"OFF" is displayed on the tester screen when each switch is turned off.

NG

REPLACE TURN SIGNAL SWITCH ASSY  
(SEE PAGE 65-25)

OK

REPLACE MULTIPLEX TILT & TELESCOPIC ECU (SEE PAGE 50-26)