


DRIVING POSITION MEMORY SWITCH CIRCUIT (W/ MEMORY)

CIRCUIT DESCRIPTION

The driver door ECU detects the condition of the driving memory switch, and sends the information to the power seat ECU and the tilt and telescopic ECU via the multiplex communication circuit.

WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 READ VALUE OF INTELLIGENT TESTER

- Connect the intelligent tester II to the DLC3.
- Turn the ignition switch ON and press the intelligent tester II main switch ON.
- Select the items below in the DATA LIST, and read the displays on the intelligent tester II.

**Driver seat ECU:**

| Item   | Measurement Item/<br>Display (Range)        | Normal Condition   |
|--------|---|--|
| M3 SW  | Seat memory switch M3 signal/<br>ON or OFF  | ON: Seat memory switch M3 is ON<br>OFF: Seat memory switch M3 is OFF |
| M2 SW  | Seat memory switch M2 signal/<br>ON or OFF  | ON: Seat memory switch M2 is ON<br>OFF: Seat memory switch M2 is OFF |
| M1 SW  | Seat memory switch M1 signal/<br>ON or OFF  | ON: Seat memory switch M1 is ON<br>OFF: Seat memory switch M1 is OFF |
| SET SW | Seat memory set switch signal/<br>ON or OFF | ON: Memory set switch is ON<br>OFF: Memory set switch is OFF         |

OK:

On the tester screen, each item should change between ON and OFF according to the above chart.


NG

Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE  
(See page 05-2281)

## 2 INSPECT DRIVING POSITION MEMORY SWITCH



- Remove the driving position memory switch.
- Measure the resistance.

**Standard:**

| Tester Connection | Switch Condition   | Specified Condition |
|-------------------|--------------------|---------------------|
| 2 - 6             | SET switch ON      | Below 1 $\Omega$    |
| 3 - 6             | Return switch 1 ON | Below 1 $\Omega$    |
| 4 - 6             | Return switch 2 ON | Below 1 $\Omega$    |
| 5 - 6             | Return switch 3 ON | Below 1 $\Omega$    |


NG

REPLACE DRIVING POSITION MEMORY SWITCH

OK

3

CHECK WIRE HARNESS (DRIVER DOOR ECU - DRIVING POSITION MEMORY SWITCH)



- (a) Disconnect the D24 ECU and D26 switch connectors
- (b) Measure the resistance of the wire harness side connectors.

Standard:

| Tester Connection        | Specified Condition |
|--------------------------|---------------------|
| D24-29(MM) - D26-2(MMR1) | Below 1 Ω           |
| D24-21(M1) - D26-3(1)    | Below 1 Ω           |
| D24-20(M2) - D26-4(2)    | Below 1 Ω           |
| D24-9(M3) - D26-5(3)     | Below 1 Ω           |
| D24-8(MSWE) - D26-6(E)   | Below 1 Ω           |

NG

REPAIR AND REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE  
(See page 05-2281)