


HEADREST LIMIT SWITCH CIRCUIT (LH)

CIRCUIT DESCRIPTION

The rear LH seat ECU detects the state of the headrest limit switch.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch ON and push the intelligent tester main switch ON.
- (c) Select the item below in the DATA LIST and read the displays on the intelligent tester.

Rear LH seat ECU:

Item	Measurement Item/ Display (Range)	Normal Condition
Hdrst Limit SW	Rear headrest limit switch signal/ ON or OFF	ON: Rear headrest limit switch is ON OFF: Rear headrest limit switch is OFF


OK:
On the tester screen, each item should change between ON and OFF according to the above chart.

OK Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2340)

2 INSPECT HEADREST LIMIT SWITCH REAR LH



- (a) Remove the headrest limit switch.
- (b) Measure the resistance of the headrest limit switch.

Standard:


Tester Connection	Switch Condition	Specified Condition
1 - 2	Not pushed (A)	10 kΩ or higher
1 - 2	Pushed (B)	Below 1 Ω

NG REPLACE HEADREST LIMIT SWITCH REAR LH

OK


3 CHECK WIRE HARNESS (REAR LH SEAT ECU - HEADREST LIMIT SWITCH REAR LH AND BODY GROUND)

Wire Harness Side



HRSW

H24
Headrest Limit
Switch Rear LH



- (a) Disconnect the R27 ECU and H24 switch connectors.
(b) Measure the resistance of the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
R27-20 (HRSW) - H24-2	Below 1 Ω
H24-1 - Body Ground	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2340)