

# SUPPLEMENTAL RESTRAINT SYSTEM

05D5V-02

## PRECAUTION

### NOTICE:

When disconnecting the negative (-) battery terminal, initialize the following systems after the terminal is reconnected.

System Name	See Page
Power Window Control System	01-20
Front Power Seat Control System	01-20
Back Guide Monitor System	01-20

### 1. HANDLING PRECAUTIONS FOR AIRBAG SENSOR

#### HINT:

In this section, the airbag sensor assy center, airbag sensor front LH, airbag sensor front RH, side airbag sensor assy LH, side airbag sensor assy RH, airbag sensor rear LH, airbag sensor rear RH and seat position airbag sensor are collectively referred to as the airbag sensor.

- (a) Before starting the following operations, wait at least 90 seconds after disconnecting the negative (-) terminal of the battery:
  - (1) Replacement of the airbag sensor.
  - (2) Adjustment of the front/rear doors of the vehicle equipped with the side airbag and curtain shield airbag (fitting adjustment).
- (b) When connecting or disconnecting the airbag sensor connector, ensure that each sensor is installed in the vehicle.
- (c) Do not use an airbag sensor which has been dropped during the operation or transportation.
- (d) Do not disassemble the airbag sensor.

### 2. INSPECTION PROCEDURE FOR VEHICLE INVOLVED IN ACCIDENT

- (a) When the airbag has not deployed, confirm the DTC by checking the SRS warning light. If there is any malfunction in the SRS airbag system, perform troubleshooting.
- (b) When any of the airbags have deployed, replace the airbag sensor and check the installation condition.