

## DATA LIST/ACTIVE TEST

### 1. DATA LIST

#### HINT:

Using the intelligent tester II DATA LIST allows switch, sensor, actuator and other items to be read without removing any parts. Reading the DATA LIST early in troubleshooting is one way to shorten labor time.

- (a) Connect the intelligent tester II to the DLC3.
- (b) Turn the ignition switch to the ON position.
- (c) Read the DATA LIST according to the display on the tester.

#### Driver side J/B ECU:

Item	Measurement Item/ Display (Range)	Normal Condition
D Seat Buckle SW	Driver seat belt buckle switch signal ON or OFF	ON: Seat belt is fastened OFF: Seat belt is unfastened