


DTC**B2043****FALL OF THE +B VOLTAGE****CIRCUIT DESCRIPTION**

This DTCs is output when one of the following occurs: 1) the voltage of the seat belt control ECU's +B terminal and IG terminal are not the same, 2) a seat belt control ECU malfunction is detected, or 3) a seat belt control ECU power supply circuit malfunction is detected.

DTC No.	DTC Detection Condition	Trouble Area
B2043	<ul style="list-style-type: none"> Voltage of +B terminal and IG terminal of seat belt control ECU are not same Seat belt control ECU malfunction is detected Seat belt control ECU power supply circuit malfunction is detected 	<ul style="list-style-type: none"> Seat belt control ECU Wire harness (Seat belt control ECU – Battery) Battery

WIRING DIAGRAM


INSPECTION PROCEDURE

1 CHECK WIRE HARNESS (SEAT BELT CONTROL ECU – BATTERY)

Wire Harness Side

S65

Seat Belt Control ECU



Y

I44437

- (a) Turn the ignition switch OFF.
- (b) Disconnect the cable from the negative (–) battery terminal.
- (c) Disconnect the S65 ECU connector.
- (d) Connect the cable to the negative (–) battery terminal.
- (e) Measure the voltage of the wire harness side connector.

Standard:

Tester Connection	Specified Condition
S65–9 (+B) – Body ground	10 to 14 V

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR (SEAT BELT CONTROL ECU – BATTERY) OR BATTERY

OK

2 CHECK DTC

- (a) Turn the ignition switch OFF.
- (b) Disconnect the cable from the negative (–) battery terminal.
- (c) Connect the connector to the seat belt control ECU.
- (d) Connect the cable to the negative (–) battery terminal.
- (e) Turn the ignition switch ON.
- (f) Clear DTCs ([see page 05-96](#)).
- (g) Turn the ignition switch OFF.
- (h) Turn the ignition switch ON.
- (i) Check for DTCs ([see page 05-96](#)).

OK: DTC is not output.

NG

REPLACE SEAT BELT CONTROL ECU
([See page 61-1](#))

OK

END