

DIAGNOSTIC TROUBLE CODE CHART

If a malfunction code is displayed during the DTC check, check the circuit listed for that code in the table below. Then proceed to the page given for that circuit.

DTC No. (See Page)	Detection Item	Trouble Area
B2211 (05-2712)	Door closer motor malfunction on driver door	<ul style="list-style-type: none"> • Cam position switch • Wire harness • Driver door ECU
B2212 (05-2714)	Door closer motor malfunction on passenger door	<ul style="list-style-type: none"> • Cam position switch • Wire harness • Passenger door ECU
B2213 (05-2716)	Door closer motor malfunction on rear right door	<ul style="list-style-type: none"> • Cam position switch • Wire harness • Rear door LH ECU
B2214 (05-2718)	Door closer motor malfunction on rear left door	<ul style="list-style-type: none"> • Cam position switch • Wire harness • Rear door RH ECU