

PROBLEM SYMPTOMS TABLE

Problem Symptom	Suspected Area	See Page
Engine does not start	1. ECU power source circuit	05-3057
	2. Transponder key/ECU Assy	05-3057