

DTC	B1421	SOLAR SENSOR CIRCUIT (PASSENGER SIDE)
-----	-------	---------------------------------------

CIRCUIT DESCRIPTION

Resistance of photodiode

High

Low

Weak Strong


Strength of solar radiation

A photodiode in the A/C solar sensor detects solar radiation and sends signals to the A/C amplifier.

DTC No.	Detection Item	Trouble Area
B1421	Solar sensor circuit (Passenger side) (Open or short)	<ul style="list-style-type: none">• A/C solar sensor• Harness or connector between A/C solar sensor and A/C amplifier• A/C amplifier

HINT:
If DTC B1244 is output at the same time, troubleshoot DTC B1244 first (see page 05-1405).

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE ON INTELLIGENT TESTER

- (a) Connect the Intelligent Tester II to the DLC3.
- (b) Turn the Ignition switch to the ON position and push the Intelligent Tester II main switch on.
- (c) Select the item below in the DATA LIST, and read the display on the Intelligent Tester II.

DATA LIST / AIR CONDITIONER:

Item	Measure Item/Display (Range)	Normal Condition	Diagnostic Note
Solar Sensor (P side) (Solar Sens-P)	Solar Sensor (Passenger side) min.: 0 max.: 255	Increases as brightness increases (Passenger side)	-

OK:
The display is as specified in the normal condition.

Result:

NG	A
OK (Checking from the PROBLEM SYMPTOM TABLE)	B
OK (Checking from the DTC)	C

B


PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-778)

C

REPLACE AIR CONDITIONING AMPLIFIER
(SEE PAGE 55-16)

A

2 INSPECT AIR CONDITIONING AMPLIFIER (TSPa)



- (a) Remove the A/C amplifier with connector still connected.
- (b) Turn the ignition switch to the ON position.
- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
A14-20 (TSPa) - Body Ground	Sensor is subjected to electric light	4.0 to 4.6 V
A14-20 (TSPa) - Body Ground	Sensor is covered by a cloth	Below 0.8 V

HINT:

- As the inspection light is moved away from the sensor, the voltage increases.
- Use an incandescent lamp for inspection. Bring it within 30 cm (11.8 in.) of the A/C solar sensor.

Result:

NG	A
OK (Checking from the PROBLEM SYMPTOMS TABLE)	B
OK (Checking from the DTC)	C

B

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE (SEE PAGE 55-778)

C


REPLACE AIR CONDITIONING AMPLIFIER (SEE PAGE 55-16)

A

3 INSPECT A/C SOLAR SENSOR

A/C Solar Sensor Connector

Front View:



I31450

- Remove the A/C solar sensor.
- Apply battery voltage between terminals A31-6 (CLTB) and A31-3 (CLTE) of the A/C solar sensor.
- Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
A31-2 (TSR) - A31-3 (CLTE) *1	Sensor is subjected to electric light	4.0 to 4.6 V
A31-2 (TSR) - A31-3 (CLTE) *1	Sensor is covered by a cloth	Below 0.8 V
A31-1 (TSL) - A31-3 (CLTE) *2	Sensor is subjected to electric light	4.0 to 4.6 V
A31-1 (TSL) - A31-3 (CLTE) *2	Sensor is covered by a cloth	Below 0.8 V

HINT:

*1: LHD

*2: RHD

NOTICE:

The connection procedure for using a digital tester such as a TOYOTA electrical tester is shown above. When using an analog tester, connect the positive (+) lead to terminal 2 and negative (-) lead to terminal 1 of the solar sensor.

HINT:

- As the inspection light is moved away from the sensor, the voltage increases.
- Use an incandescent lamp for inspection. Bring it within 30 cm (11.8 in.) of the solar sensor.


NG

REPLACE A/C SOLAR SENSOR

OK

4

CHECK HARNESS AND CONNECTOR (A/C SOLAR SENSOR - AIR CONDITIONING AMPLIFIER) (SEE PAGE 01-44)



(a) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
A14-20 (TSPa) - A31-2 *1	Always	Below 1 Ω
A14-20 (TSPa) - A31-1 *2	Always	Below 1 Ω
A14-20 (TSPa) - Body ground	Always	10 kΩ or higher

HINT:

*1: LHD

*2: RHD

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

REPLACE AIR CONDITIONING AMPLIFIER (SEE PAGE 55-16)