


INSPECTION PROCEDURE

1 INSPECT AFS ECU



(a) Measure the voltage according to the value(s) in the table below.

Standard:


Tester Connection	Condition	Specified Condition
A40-1 - A40-2	Ignition switch OFF	Below 1 V
A40-1 - A40-2	Ignition switch ON	10 to 14 V

NG Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(SEE PAGE 05-1369)

2 CHECK HARNESS AND CONNECTOR (GROUND CIRCUIT)



- (a) Disconnect the A40 connector from the AFS ECU.
(b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester Connection	Condition	Specified Condition
A40-1 - Body ground	Always	Below 1 Ω

NG REPAIR OR REPLACE HARNESS OR CONNECTOR (GROUND CIRCUIT)

OK

REPAIR OR REPLACE HARNESS OR CONNECTOR (IGNITION SWITCH CIRCUIT)