


LUGGAGE ELECTRICAL KEY SWITCH (PUSH SWITCH) CIRCUIT (W/ SMART KEY SYSTEM)

CIRCUIT DESCRIPTION

Open and close operations of the luggage door is monitored, and the signals are sent to the luggage room J/B ECU.

WIRING DIAGRAM



INSPECTION PROCEDURE

1 READ VALUE OF INTELLIGENT TESTER II (LUGGAGE ELECTRICAL KEY SWITCH (PUSH SWITCH))

(a) Check the DATA LIST for proper functioning of the luggage electrical key switch.

Luggage room J/B ECU:

Item	Measurement Item / Display (Range)	Normal Condition	Diagnostic Note
Lugg Push SW	Luggage electrical key switch signal ON or OFF	ON: Luggage electrical key switch is pushed OFF: Luggage electrical key switch is not pushed	-


OK: "ON" (luggage electrical key switch is pushed) appears on the screen.

NG Go to step 2

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2782)

2 INSPECT LUGGAGE ELECTRICAL KEY SWITCH (PUSH SWITCH)



(a) Measure the resistance between the terminals of the connector when the switch is operated.

Standard:

Tester Connection	Switch Condition	Specified Condition
1 - 2	Pushed	Below 1 Ω
1 - 2	Not push	10 k Ω or higher


NG **REPAIR LUGGAGE ELECTRICAL KEY SWITCH (PUSH SWITCH)**

OK


3 CHECK WIRE HARNESS (LUGGAGE ELECTRICAL KEY SWITCH (PUSH SWITCH) – LUGGAGE ROOM J/B ECU AND BODY GROUND)

Wire Harness Side

L5
Luggage Electrical Key Switch



L11
Luggage Room J/B ECU



Y

B78393

- (a) Disconnect L5 switch connector.
- (b) Disconnect L11 ECU connector.
- (c) Measure the resistance of the wire harness side connectors.

Tester Connection	Specified Condition
L5-2 – L11-3 (LPSW)	Below 1 Ω
L5-1 – Body ground	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2782)