

SEAT HEATER SYSTEM

LOCATION

BE0CT-03

- Driver Side J/B
- PANEL Fuse
 - Driver Side J/B ECU
 - RR S/HTR Fuse

- Passenger Side J/B
- FR S/HTR Fuse
 - P-IG Fuse

Seat Heater Switch
(Telltale Light Switch)

