

PROBLEM SYMPTOMS TABLE

Symptom	Suspected Area	See Page
Driver side seat belt warning lamp does not blink	1. DOME fuse	61-1
	2. GAUGE fuse	61-1
	3. D-IG1 relay	61-1
	4. Combination meter	05-2187
	5. Front seat inner belt assy (driver side)	61-6
	6. Wire harness	–
Passenger side seat belt warning lamp does not blink	1. DOME fuse	61-1
	2. GAUGE fuse	61-1
	3. P-IG fuse	61-1
	4. P-IG1 relay	61-1
	5. Front seat inner belt assy (passenger side)	61-6
	6. Occupant detection sensor	61-6
	7. Multi-display (w/ LEXUS navigation)	05-2190
	8. Clock (w/o LEXUS navigation)	05-2190
	9. Airbag sensor assy	05-951
	10. Wire harness	–

HINT:

The seat belt warning system is part of the large-scale multiplex communication system. This system features shared communication wiring that reduces the wiring complexity of the communication lines. The first step in any repair is to confirm the proper operation of the communication system. Proceed with troubleshooting after the communication has been verified (see the Multiplex Communication System).