

## DATA LIST/ACTIVE TEST

### 1. DATA LIST

#### HINT:

Using the Intelligent Tester II, DATA LIST allows switch, sensor, actuator and other item values to be read without removing any parts. Reading the DATA LIST early in troubleshooting is one way to shorten labor time.

- Connect the Intelligent Tester II to the DLC3.
- Turn the ignition switch ON.
- Read the DATA LIST according to the display on the tester.

#### Driver door ECU, Passenger door ECU, Rear door ECU LH and Rear door ECU RH

Item	Measurement Item/ Display (Range)	Normal Condition	Diagnostic Note
Cam Pos SW3	Cam position switch 3	Refer to system description of closer motor and cam position switch (see page 05-2695)	–
Cam Pos SW2	Cam position switch 2	Refer to system description of closer motor and cam position switch (see page 05-2695)	–
Cam Pos SW1	Cam position switch 1	Refer to system description of closer motor and cam position switch (see page 05-2695)	–
Pole SW	POLE SW	Refer to system description of door ECU (see page 05-2695)	–
Half SW	HALF SW	Refer to system description of door ECU (see page 05-2695)	–
Full SW	FULL SW	Refer to system description of door ECU (see page 05-2695)	–