



REMOVAL

REMOVE HEADLIGHT ASSEMBLY

- (a) Remove the 3 clips and cover.
- (b) Remove the 2 bolts.
- (c) Disconnect the connector, then remove the headlight assembly.
- (d) Employ the same manner described above to the other side.

HINT:

At the time of installation, please refer to the following items.

- If the headlight brackets are damaged, the headlight assembly can be reinstalled to the body by installing the brackets for repair to it.
- When installing the brackets for repair, cut off the damaged parts of the headlight bracket so that the brackets can be installed properly.

