

DTC	U0126	COMMUNICATION ERROR OF STEERING SENSOR
------------	--------------	---

CIRCUIT DESCRIPTION

This circuit detects the angle and direction of steering and automatically transmits its signal to the skid control ECU and distance control ECU.

DTC No.	DTC Detecting Condition	Trouble Area
U0126	While the dynamic laser cruise control is either preparing for operation or operating, if the ECM continuously receives a steering sensor malfunction signal for a certain amount of time, distance control ECU sends a signal to the ECM to record this trouble code.	<ul style="list-style-type: none">• Communication circuit• Steering sensor• Cruise control ECU (Distance control ECU)• ECM

INSPECTION PROCEDURE

HINT:

This circuit uses CAN for communication. Therefore, if there are any malfunctions in the communication circuit, one or more DTCs in the CAN communication system is/are output.

1	GO TO CAN COMMUNICATION SYSTEM (SEE PAGE 05-3306)
---	---