

PROBLEM SYMPTOMS TABLE

Use the table below to help find the cause of the problem. The numbers indicate the priority of the likely possible cause of the problem. Check each part in order. Replace parts as necessary.

Symptom	Suspected Area	See page
Brake drag	1. Parking brake pedal travel (Out of adjustment)	33-3
	2. Parking brake wire (Sticking)	33-15
		33-25
	3. Parking brake shoe clearance (Out of adjustment)	33-33
	4. Parking brake shoe lining (Cracked or distorted)	33-33
	5. Tension or return spring (Damaged)	33-33