

## TORQUE SPECIFICATION

Part Tightened	N·m	kgf·cm	ft·lbf
Refill plug x Transmission assy	39	400	53
Overflow plug x Transmission assy	20	204	15
Transmission case cover x Transmission assy	5.4	55	48 in.·lbf
Park/neutral position switch x Adjust bolt	13	130	9
Control shaft lever x Park/neutral position switch	16	160	12
Engine rear mounting member x Body	26	270	20
Floor shift gear shifting rod x Shift lever assy	13	130	9
Transmission revolution sensor x Transmission assy	5.4	55	48 in.·lbf
Drain plug x Transmission assy	20	205	15
Transmission control shaft lever RH x Park/neutral position switch	16	160	12
Engine mounting insulator rear No.1 x Transmission assy	12	122	9
Transmission assy x Engine	Bolt A:	37	27
	Bolt B:	71	52
Torque converter clutch x Drive plate	48	490	35
Flywheel housing under cover x Transmission assy	18	184	13
Wire harness x Transmission assy	Bolt A:	68	51
	Bolt B:	7.5	66 in.·lbf
Engine rear mounting member x Transmission assy	12	122	9
Engine rear mounting member x Body	26	270	20
Clamp x Transmission assy	5.0	50	43 in.·lbf
Oil cooler outlet tube No.1 x Transmission assy	44	450	32
Oil cooler inlet tube No.1 x Transmission assy	44	450	32
Exhaust pipe No.1 support bracket x Transmission assy	44	450	32
Transmission wire x Transmission assy	5.4	55	48 in.·lbf
Clamp x Transmission valve body	10	100	7
ATF temperature sensor x Transmission valve body	10	100	7
Valve body oil strainer assy x Transmission valve body	10	100	7
Automatic transmission oil pan x Transmission assy	4.4	44	39
Solenoid valve (SL1, SLT) x Valve body	6.4	65	56 in.·lbf
Solenoid valve (SR) x Valve body	10	100	7
Solenoid valve (S1) x Valve body	10	100	7
Solenoid valve (S2, S4) x Valve body	10	100	7
Solenoid valve (S3) x Valve body	10	100	7
Solenoid valve (SLU, SL2) x Valve body	6.4	65	56 in.·lbf
Valve body x Transmission assy	11	110	8
Floor shift assy x Body	8.3	85	74 in.·lbf