



POWER SOURCE CIRCUIT (AUDIO AND REAR A/C CONTROL SW)

CIRCUIT DESCRIPTION

This circuit provides the power to the audio and rear A/C control switch.


WIRING DIAGRAM





INSPECTION PROCEDURE

1 INSPECT AUDIO AND REAR A/C CONTROL SWITCH(+B, ACC, GND)



- (a) Disconnect the audio and rear A/C control switch connector A50.
- (b) Measure the resistance according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
GND - Body ground	Always	Below 1 Ω

- (c) Measure the voltage according to the value(s) in the table below.

Standard:

Tester connection	Condition	Specified condition
+B - GND	Always	10 to 14 V
ACC - GND	Ignition SW ACC	10 to 14 V

NG

REPAIR OR REPLACE HARNESS OR CONNECTOR

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE OR DIAGNOSTIC TROUBLE CODE CHART (SEE PAGE 05-1660 OR 05-1673)