


DTC	B1279	RAIN SENSOR COMMUNICATION STOP
-----	-------	--------------------------------

CIRCUIT DESCRIPTION

This DTC is detected when communication between the rain sensor and overhead J/B stops for more than 10 seconds.


DTC No.	DTC Detection Condition	Trouble Area
B1279	Rain sensor communication stops	<ul style="list-style-type: none">• Rain sensor• Wire harness

WIRING DIAGRAM



INSPECTION PROCEDURE

1 CHECK RESISTANCE OF COMMUNICATION LINE



- (a) Disconnect the R8 sensor connector.
- (b) Disconnect the O6 J/B connector.
- (c) Measure the resistance between the wire harness side connectors.

Standard:

Tester Connection	Specified Condition
R8-1 (SIG) – O6-12 (IG2)	Below 1 Ω
R8-2 (MPX) – O6-30 (MPX1)	Below 1 Ω
R8-3 (ES) – O6-15 (GND2)	Below 1 Ω

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

REPLACE RAIN SENSOR