



INSTALLATION

NOTICE:

- Never use SRS parts from another vehicle. When replacing parts, replace them with new parts.
- Never reuse the sensor involved in a collision when the SRS has deployed.
- Never repair a sensor in order to reuse it.

1. INSTALL FRONT AIRBAG SENSOR LH AND RH

- (a) Install the front airbag sensors with the 2 bolts.

Torque: 20 N·m (205 kgf·cm, 15 ft·lbf)

NOTICE:

- Connection of the connector is done after the sensor assembly has been installed.
- Make sure the sensor is installed with the specified torque.
- If the sensor has been dropped, or there are cracks, dents or other defects in the case, brackets or connector, replace the removed sensor with a new one.
- The front sensor is equipped with an electrical connection check mechanism. Be sure to lock this mechanism securely when connecting the connector. If the connector is not securely locked, a malfunction code will be detected by the diagnostic system.

- (b) Connect the front airbag sensor connector.

2. INSTALL AIR CLEANER ASSEMBLY

Install the air cleaner assembly with the 3 bolts.

3. INSTALL NO. 1 AIR CLEANER INLET

Install the No. 1 air cleaner inlet with the 2 bolts.