

## REPLACEMENT

### REPLACEMENT REQUIREMENTS

In the following cases, replace the seat position sensor assembly.

- If the seat position sensor assembly has been found to be faulty in troubleshooting.
- If the seat position sensor assembly has been dropped.

### CAUTION:

For removal and installation of the seat position sensor assembly, [see page RS-55](#) and [RS-58](#). Be sure to follow the correct procedure.