

PROBLEM SYMPTOMS TABLE

Symptoms	Suspected Area	See Page
Smart unlock does not operate	1. Smart key (Transmitter) 2. Wireless tuner circuit (inner mirror, Luggage) 3. Touch sensor circuit 4. Door oscillator circuit 5. Antenna circuit 6. Door ECU 7. Theft warning ECU (Theft deterrent ECU)	05-2690 05-2879 05-2668 05-2658 05-2677 05-2551 05-3059
Smart lock does not operate	1. Smart key (Transmitter) 2. Wireless tuner circuit (inner mirror, Luggage) 3. Trigger switch circuit 4. Door oscillator circuit 5. Antenna circuit 6. Door ECU 7. Theft warning ECU (Theft deterrent ECU)	05-2690 05-2879 05-2673 05-2658 05-2677 05-2551 05-3059
Smart luggage open does not operate	1. Smart key (Transmitter) 2. Wireless tuner circuit (inner mirror, Luggage) 3. Luggage compartment door push switch circuit 4. Luggage oscillator circuit (inner, Outer) 5. Luggage room J/B 6. Theft warning ECU (Theft deterrent ECU)	05-2690 05-2879 05-2792 05-2680 05-2789 05-3059
Smart ignition does not operate	1. Smart key (Transmitter) 2. Wireless tuner circuit (inner mirror, Luggage) 3. Room oscillator circuit (inner, Outer) 4. Theft warning ECU 5. Steering lock system	05-2690 05-2879 05-2683 05-3059 05-723
Smart indicator lamp does not illuminate or flash continuously	1. Smart indicator circuit 2. Door unlock detection switch circuit 3. Door ECU 4. Theft warning ECU (Theft deterrent ECU)	05-2655 05-2564 05-2551 05-3059
Smart system does not cancel	1. Smart key cancel switch circuit 2. Theft warning ECU (Theft deterrent ECU)	05-2652 05-3059
Smart buzzer does not sound	1. Wireless door lock control system 2. Theft warning ECU (Theft deterrent ECU)	05-2841 05-3059
Room lamp does not operate when smart system is operating	1. Lighting system 2. Theft warning ECU (Theft deterrent ECU)	05-1340 05-3059
Front foot lamp does not illuminate	1. Lighting system 2. Theft warning ECU (Theft deterrent ECU)	05-1340 05-3059
Smart answer-back does not occur	1. Smart key (Transmitter) 2. Wireless tuner circuit (inner mirror, Luggage) 3. Theft warning ECU (Theft deterrent ECU)	05-2690 05-2879 05-3059
Smart window up does not operate	1. Smart key (Transmitter) 2. Wireless tuner circuit (inner mirror Luggage) 3. Trigger switch circuit 4. Sliding roof system 5. Power window control system 6. Door ECU 7. Theft warning ECU	05-2690 05-2879 05-2673 05-2945 05-1974 05-2551 05-3059