

## M PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
A 1	A/C Ambient Temp. Sensor	90980-11070	B 1	Brake Fluid Level Warning SW	90980-11207
A 2	A/C Magnetic Clutch and Lock Sensor	90980-11016	B 2	Blower Motor	90980-11667
A 3	A/C Pressure Sensor	90980-10845	B 3	Brake Pedal Load Sensing SW	90980-10860
A 4	A/C Solenoid	90980-10901	B 4	Buckle SW Front LH (LHD)	90980-10795
A 5	ABS & TRC & VSC Actuator	90980-11451		Buckle SW Front LH (RHD)	90980-11194
A 6	ABS & TRC & VSC Actuator	90980-11893	B 5	Buckle SW Front RH (LHD)	90980-11194
A 7	ABS Speed Sensor and Pad Wear Indicator SW Front RH	90980-11291		Buckle SW Front RH (RHD)	90980-10795
A 8	ABS Speed Sensor Front LH	90980-11247	B 6	Buckle SW Rear LH	90980-10795
A 9	Air Flow Meter	90980-11317	B 7	Buckle SW Rear RH	
A10	Airbag Sensor Front LH	90980-11856	C 1	Camshaft Position Sensor	90980-10947
A11	Airbag Sensor Front RH		C 2	Camshaft Timing Oil Control Valve LH	90980-11162
A12	Alternator	90980-09363	C 3	Camshaft Timing Oil Control Valve RH	
A13	Alternator	90980-11349	C 4	Crankshaft Position Sensor	
A14	A/C Control Assembly	90980-11421	C 5	Cellular Phone	90980-11912
A15	A/C Control Assembly	90980-11476	C 6	Center Cluster Integration Panel	90980-11923
A16	A/C Control Assembly	90980-11586	C 7	Cigarette Lighter (Front) (LHD)	90980-11399
A17	A/C Room Temp. Sensor (LHD)	90980-10825		Cigarette Lighter (Front) (LHD)	90980-10858
	A/C Room Temp. Sensor (RHD)	90980-11918	C 8	Cigarette Lighter (Rear)	
A18	A/C Room Temp. SW (Driver's Side)	90980-11923	C 9	Clearance Sonar Buzzer (Front)	90980-10825
A19	A/C Room Temp. SW (Front Passenger's Side)	90980-11909	C10	Clock	90980-12113
A20	A/T Shift Lever Illumination	90980-11918	C11	Coin Box Illumination	90980-11918
A21	Absorber Control SW	90980-11950	C12	Combination Meter	90980-11915
A22	Accel Position Sensor	90980-11144	C13	Combination SW	90980-11986
A23	Air Suspension ECU	90980-11390	C14	Combination SW	90980-11911
A24	Air Suspension ECU	90980-11391	C15	Console Box Illumination	90980-10886
A25	Air Suspension ECU	90980-11392	C16	Clearance Sonar Buzzer (Rear)	90980-10825
A26	Airbag Sensor Assembly	82824-50160	C17	Clearance Sonar ECU	90980-11877
A27	Airbag Sensor Assembly	90980-11872	C18	Curtain Shield Airbag Squib LH	90980-11884
A28	Airbag Sensor Assembly	82824-50150	C19	Curtain Shield Airbag Squib RH	
A29	Airbag Squib (Front Passenger Airbag Assembly)	90980-12160	C20	Climate Control Seat ECU (Driver's Seat)	82824-50190
	Airbag Squib (Steering Wheel Pad)		C21	Climate Control Seat ECU (Front Passenger's Seat)	
A30	Airbag Squib (Steering Wheel Pad)	90980-11884	C22	Cooling Fan ECU	90980-12058
A31	Automatic Light Control Sensor and A/C Solar Sensor (Front)	90980-12056	C23	Cooling Fan ECU	90980-10837
A32	A/C Solar Sensor (Rear)	90980-10825	C24	Cooling Fan ECU	90980-10841
A33	ABS Speed Sensor and Pad Wear Indicator SW Rear RH	90980-10794	D 1	DLC3	90980-11665
A34	ABS Speed Sensor Rear LH	90980-10859	D 2	Driver Side J/B ECU	90980-11973
A35	Acceleration Sensor	90980-10845	D 3	Driver Side J/B ECU	90980-11923
A36	Ashtray Illumination Rear LH	90980-12111	D 4	Driver Side J/B ECU	
A37	Ashtray Illumination Rear RH		D 5	Driver Side J/B ECU	90980-11915
A38	Audio and Rear A/C Control SW (w/ Rear Power Seat)	90980-11922	D 6	Duct Sensor (Driver's Side)	90980-10825
	Audio and Rear A/C Control SW (w/o Rear Power Seat)	90980-12025	D 7	Duct Sensor (Front Passenger's Side)	
			D 8	Door Courtesy Light Front LH	90980-11148
			D 9	Door Courtesy Light Front RH	

Note: Not all of the above part numbers of the connector are established for the supply.

Nota: Toutes les références du connecteur ne sont pas définies pour la fourniture.

Code	Part Name	Part Number	Code	Part Name	Part Number
D10	Door Courtesy Light Rear LH	90980-11148	F16	Front Passenger Door ECU	90980-12151
D11	Door Courtesy Light Rear RH		F17	Front Passenger Door ECU	90980-12150
D12	Door Courtesy SW Front LH	90980-10871	F18	Fuel Lid Opener Motor	90980-11019
D13	Door Courtesy SW Front RH		F19	Fuel Pump and Fuel Sender (Main)	90980-11077
D14	Door Courtesy SW Rear LH		F20	Fuel Sender (Sub)	90980-12168
D15	Door Courtesy SW Rear RH		G 1	Gateway ECU	90980-11915
D16	Door Lock Control Receiver	90980-11950	G 2	Glove Box Light No.1	90980-11918
D17	Door Lock Control SW Front LH		G 3	Glove Box Light No.2	
D18	Door Lock Control SW Front RH		H 1	Headlight Beam Level Control Actuator LH	90980-11144
D19	Door Lock SW (Luggage)	90980-11141	H 2	Headlight Beam Level Control Actuator RH	
D20	Door Oscillator Front LH (w/ Sensor)	90980-11923	H 3	Headlight Cleaner Control Relay	90980-10939
D21	Door Oscillator Front RH (w/ Sensor)		H 4	Headlight Cleaner Motor	90980-11410
D22	Door Oscillator Rear LH (w/ Sensor)		H 5	Headlight Control ECU LH	90980-11003
D23	Door Oscillator Rear RH (w/ Sensor)		H 6	Headlight Control ECU RH	
D24	Driver Door ECU	90980-12151	H 7	Headlight LH (High)	90980-11095
D25	Driver Door ECU	90980-12150	H 8	Headlight RH (High)	
D26	Driving Position Memory SW	90980-11989	H 9	Heated Oxygen Sensor (Bank 1 Sensor 1)	90980-10869
D27	Driver Seat ECU	90980-10807	H10	Heated Oxygen Sensor (Bank 2 Sensor 1)	
D28	Driver Seat ECU	90980-12094	H11	Height Control Compressor	90980-10990
E 1	ECT Solenoid	90980-11151	H12	Height Control Exhaust Valve	90980-11156
E 2	EFI Water Temp. Sensor	90980-10736	H13	Height Control Sensor Front LH	90980-11929
E 3	Engine and ECT ECU	90980-12146	H14	Height Control Sensor Front RH	
E 4	Engine and ECT ECU	90980-12142	H15	Horn (High)	90980-10619
E 5	Engine and ECT ECU	90980-12143	H16	Horn (Low)	
E 6	Engine and ECT ECU	90980-12144	H17	Hazard SW (w/ LEXUS Navigation System)	90980-10801
E 7	Engine and ECT ECU	90980-12145		Hazard SW (w/o LEXUS Navigation System)	90980-11950
E 8	Engine Hood Courtesy SW	90980-11189	H18	Headlight Beam Level Control ECU	90980-11406
E 9	Engine Oil Level Sensor	90980-11235	H19	Heated Oxygen Sensor (Bank 1 Sensor 2) (LHD)	90980-10858
E10	Exhaust Gas Sensor	90980-11034		Heated Oxygen Sensor (Bank 1 Sensor 2) (RHD)	90980-11399
E11	ECT Pattern Select SW	90980-11986	H20	Heated Oxygen Sensor (Bank 2 Sensor 2) (LHD)	
F 1	Front Clearance Light LH	90980-11156		Heated Oxygen Sensor (Bank 2 Sensor 2) (RHD)	90980-10858
F 2	Front Clearance Light RH		H21	Height Control SW	90980-11909
F 3	Front Fog Light LH	90980-11096	H22	Height Control Sensor Rear (w/o Electronically Modulated Air Suspension)	90980-11298
F 4	Front Fog Light RH			Height Control Sensor Rear (w/ Electronically Modulated Air Suspension)	90980-11922
F 5	Front Height Control Valve	90980-11143	H23	High Mounted Stop Light	90980-10825
F 6	Front Side Turn Signal Light LH	90980-11162	H24	Head Rest Limit SW Rear LH	
F 7	Front Side Turn Signal Light RH		H25	Head Rest Limit SW Rear RH	
F 8	Front Turn Signal Light LH	90980-11019	I 1	Ignition Coil and Igniter No.1	90980-11885
F 9	Front Turn Signal Light RH		I 2	Ignition Coil and Igniter No.2	
F10	Front Wiper Motor	90980-11290	I 3	Ignition Coil and Igniter No.3	
F11	Fuel Pump Resistor	90980-11003			
F12	Fuel Lid Opener SW	90980-10825			
F13	Fuel Lid Opener SW Illumination	90980-11013			
F14	Front Door Speaker LH	90980-10935			
F15	Front Door Speaker RH				

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro.

Anmerkung: Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert.

## M PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
I 4	Ignition Coil and Igniter No.4	90980-11885	J24	Junction Connector	90980-11686
I 5	Ignition Coil and Igniter No.5		J25	Junction Connector	90980-11915
I 6	Ignition Coil and Igniter No.6		J26	Junction Connector	
I 7	Ignition Coil and Igniter No.7		J27	Junction Connector	90980-10976
I 8	Ignition Coil and Igniter No.8		J28	Junction Connector	90980-11661
I 9	Injector No.1	90980-11153	J29	Junction Connector	
I10	Injector No.2		J30	Junction Connector	90980-11686
I11	Injector No.3		J31	Junction Connector	90980-11915
I12	Injector No.4		J32	Junction Connector	90980-11398
I13	Injector No.5		K 1	Keyless Buzzer	90980-11156
I14	Injector No.6		K 2	Knock Sensor LH	90980-11166
I15	Injector No.7		K 3	Knock Sensor RH	
I16	Injector No.8		K 4	Keyless Buzzer On/Off SW	90980-10860
I17	Ignition SW	90980-11778	K 5	Kick Down SW	90980-11156
I18	Instrument Panel Register	90980-12135	L 1	Luggage Compartment Door Opener SW	90980-10860
I19	Inner Mirror	90980-11989	L 2	License Plate Light LH	90980-11148
I20	Inside Handle Illumination Front LH	90980-12063	L 3	License Plate Light RH	
I21	Inside Handle Illumination Front RH		L 4	Luggage Compartment Door Closer Motor	90980-11011
I22	Inside Handle Illumination Rear LH		L 5	Luggage Compartment Door Courtesy SW	90980-11825
I23	Inside Handle Illumination Rear RH		L 6	Luggage Compartment Door Key Unlock SW	90980-10825
I24	Interior Light Rear LH	90980-11909	L 7	Luggage Compartment Light No.1	90980-11148
I25	Interior Light Rear RH		L 8	Luggage Compartment Light No.2	
J 1	Junction Connector	90980-11661	L 9	Luggage Oscillator (Inner)	90980-11909
J 2	Junction Connector		L10	Luggage Oscillator (Outer)	
J 3	Junction Connector		L11	Luggage Room J/B ECU	90980-11911
J 4	Junction Connector		L12	Luggage Room J/B ECU	90980-11923
J 5	Junction Connector		L13	Luggage Room J/B ECU	90980-11915
J 6	Junction Connector		M 1	Multi-Display	90980-10799
J 7	Junction Connector	90980-11542	M 2	Multi-Display	90980-11911
J 8	Junction Connector	90980-11537	M 3	Multi-Display	90980-11923
J 9	Junction Connector	90980-11398	M 4	Moon Roof Control ECU	90980-10997
J10	Junction Connector		N 1	Neutral Start SW	90980-11784
J11	Junction Connector	90980-11915	N 2	Noise Filter (Ignition Left Bank)	90980-10843
J12	Junction Connector		N 3	Noise Filter (Ignition Right Bank)	
J13	Junction Connector		N 4	Noise Filter (Rear Window Defogger)	90980-11184
J14	Junction Connector		N 5	Navigation ECU	90980-11973
J15	Junction Connector		N 6	Navigation ECU	90980-11923
J16	Junction Connector		N 7	Noise Filter (Rear Window Defogger)	90980-10916
J17	Junction Connector		O 1	O/D Direct Clutch Speed Sensor	90980-11156
J18	Junction Connector		O 2	Oil Pressure SW	90980-11363
J19	Junction Connector	90980-11398	O 3	Outer Mirror SW	90980-11657
J20	Junction Connector		O 4	Outer Mirror SW	90980-11989
J21	Junction Connector		O 5	Outer Mirror SW (LHD)	90980-11950
J22	Junction Connector	90980-10976		Outer Mirror SW (RHD)	90980-11090
J23	Junction Connector	90980-11915			

Note: Not all of the above part numbers of the connector are established for the supply.

*Nota: Toutes les références du connecteur ne sont pas définies pour la fourniture.*

Code	Part Name	Part Number	Code	Part Name	Part Number
O 6	Overhead J/B	90980-12153	P36	Power Seat Motor (Front Passenger's Seat Lifter Control)	90980-10825
P 1	PPS Solenoid	90980-11162	P37	Power Seat Motor (Front Passenger's Seat Lumbar Support Control)	
P 2	Parking Brake SW	90980-10871	P38	Power Seat Motor (Front Passenger's Seat Reclining Control)	
P 3	Passenger Side J/B ECU	90980-11973	P39	Power Seat Motor (Front Passenger's Seat Slide Control)	
P 4	Passenger Side J/B ECU	90980-11915	P40	Power Seat Motor and Position Sensor (Driver's Seat Head Rest Control)	90980-11085
P 5	Passenger Side J/B ECU	90980-11923	P41	Power Seat Position Sensor (Driver's Seat Cushion Control)	90980-10908
P 6	Power Outlet	90980-11155	P42	Power Seat Position Sensor (Driver's Seat Front Vertical Control)	
P 7	Power Tilt and Power Telescopic ECU	90980-10799	P43	Power Seat Position Sensor (Driver's Seat Lifter Control)	
P 8	Power Tilt and Power Telescopic ECU	90980-10848	P44	Power Seat Position Sensor (Driver's Seat Reclining Control)	
P 9	Power Window Control SW Front LH	90980-12113	P45	Power Seat Position Sensor (Driver's Seat Slide Control)	90980-10908
P10	Power Window Control SW Front RH		P46	Power Seat Motor (Rear Passenger's LH Seat Slide Control)	
P11	Power Window Control SW Rear LH		P47	Power Seat Motor (Rear Passenger's RH Seat Slide Control)	
P12	Power Window Control SW Rear RH		P48	Power Seat Motor and Position Sensor (Rear Passenger's LH Seat Head Rest Top and Bottom Control)	90980-10789
P13	Power Window Master SW	90980-12166	P49	Power Seat Motor and Position Sensor (Rear Passenger's RH Seat Head Rest Top and Bottom Control)	
P14	Power Window Motor Front LH	90980-10797	P50	Power Seat Position Sensor (Rear Passenger's LH Seat Slide Control)	90980-10908
P15	Power Window Motor Front RH		P51	Power Seat Position Sensor (Rear Passenger's RH Seat Slide Control)	
P16	Power Window Motor Rear LH	90980-11011	R 4	Radio and Player	90980-12038
P17	Power Window Motor Rear RH		R 5	Radio and Player	90980-12012
P18	Pretensioner Front LH	90980-12138	R 6	Rheostat	90980-11989
P19	Pretensioner Front RH		R 7	Room Oscillator (Front)	90980-11909
P20	Pretensioner Rear LH	90980-11862	R 8	Rain Sensor	90980-11987
P21	Pretensioner Rear RH		R 9	Rear A/C Unit	90980-10830
P22	Power Seat Control SW (Driver's Seat Cushion)	90980-10601	R10	Rear Combination Light LH	90980-11587
P23	Power Seat Control SW (Driver's Seat Lumbar Support)	90980-10964	R11	Rear Combination Light LH	
P24	Power Seat Control SW (Front Passenger's Seat Lumbar Support)	90980-10601	R12	Rear Combination Light RH	
P25	Power Seat Control SW (Front Passenger's Seat)	90980-10807	R13	Rear Combination Light RH	
P26	Power Seat Control SW Sub (Front Passenger's Seat)	90980-10801	R14	Rear Door LH ECU	90980-12151
P27	Power Seat Motor (Driver's Seat Cushion Control)	90980-10825	R15	Rear Door LH ECU	90980-12150
P28	Power Seat Motor (Driver's Seat Front Vertical Control)		R16	Rear Door RH ECU	
P29	Power Seat Motor (Driver's Seat Lifter Control)		R17	Rear Door RH ECU	90980-12151
P30	Power Seat Motor (Driver's Seat Lumbar Support Lower Side Control)		R18	Rear Door Speaker LH	90980-10935
P31	Power Seat Motor (Driver's Seat Lumbar Support Upper Side Control)		R19	Rear Door Speaker RH	
P32	Power Seat Motor (Driver's Seat Reclining Control)		R20	Rear Height Control Valve	90980-11860
P33	Power Seat Motor (Driver's Seat Slide Control)				
P34	Power Seat Motor (Front Passenger's Seat Front Vertical Control)				
P35	Power Seat Motor (Front Passenger's Seat Head Rest Control)	90980-11085			

Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro.

Anmerkung: Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert.

## M PART NUMBER OF CONNECTORS

Code	Part Name	Part Number	Code	Part Name	Part Number
R21	Rear Seat Memory SW LH	90980-11989	S34	Stereo Component Amplifier	90980-10848
R22	Rear Seat Memory SW RH		S35	Stereo Component Tuner	90980-11877
R23	Rear Sunshade Control Relay	90980-10789	S36	Suspension Control Actuator Rear LH	90980-10789
R24	Rear Window Defogger	90980-11259	S37	Suspension Control Actuator Rear RH	
R25	Rear Window Defogger	90980-10914	S38	Seat Climate Controller LH	90980-11920
R26	Room Oscillator (Rear)	90980-11920	S39	Seat Climate Controller RH	
R27	Rear LH Seat ECU	90980-11877	S40	Seat Heater Front LH	90980-10907
R28	Rear RH Seat ECU		S41	Seat Heater Front RH	
R29	Rear Seat Control SW	90980-12025	S42	Side Airbag Squib LH	90980-11864
S 1	Short Connector (LHD)	90980-11922	S43	Side Airbag Squib RH	
	Short Connector (RHD)	90980-11920	S44	Seat Heater Rear LH	90980-10795
S 2	Short Connector (LHD)	90980-11923	S45	Seat Heater Rear RH	
	Short Connector (RHD)	90980-11909	T 1	Theft Deterrent Horn	90980-10619
S 3	Speed Sensor	90980-11156	T 2	Throttle Control Motor	90980-11156
S 4	Starter	90980-09585	T 3	Throttle Position Sensor	90980-10711
S 5	Starter	90980-11400	T 4	Telescopic Motor and Position Sensor	90980-10799
S 6	Suspension Control Actuator Front LH	90980-10789	T 5	Theft Deterrent ECU	90980-12169
S 7	Suspension Control Actuator Front RH		T 6	Tilt Motor and Position Sensor	90980-10799
S 8	Shift Lock Control ECU	90980-11923	T 7	Traction Control SW, Seat Heater SW LH, Seat Heater SW RH, Climate Control Seat SW LH, Climate Control Seat SW RH, Headlight Cleaner SW, Rear Sunshade SW, Rear Seat Reset SW	90980-11915
S 9	Short Connector (Height Control)	90980-12002			
S10	Short Connector (Height Control)	90980-12003			
S11	Skid Control ECU	90980-11421			
S12	Skid Control ECU	90980-11476	T 8	Transponder Key Amplifier	90980-12092
S13	Skid Control ECU	90980-11637	T 9	Transponder Key Computer	90980-11911
S14	Skid Control ECU	90980-11638	T10	Trip SW	90980-11490
S15	Smart Key System Cancel SW	90980-10825	T11	Tweeter Front LH	90980-10860
S16	Speed Warning Buzzer	90980-11148	T12	Tweeter Front RH	
S17	Steering Lock ECU	90980-11913	T13	Telephone Transceiver and Speaker Relay	90980-11912
S18	Steering Sensor	90980-12162	T14	Telephone Transceiver and Speaker Relay	90980-12025
S19	Step Light LH	90980-12063	T15	Telephone Transceiver and Speaker Relay	90980-11971
S20	Step Light RH		T16	Theft Deterrent Siren	90980-11034
S21	Stop Light SW	90980-10795	T17	Tweeter Rear LH	90980-10795
S22	Shoulder Belt Adjust SW Front LH	90980-11987	T18	Tweeter Rear RH	
S23	Shoulder Belt Adjust SW Front RH		U 1	Ultrasonic Sensor (Front Left Center)	90980-11246
S24	Shoulder Belt Anchor Motor and Position Sensor LH	90980-12056	U 2	Ultrasonic Sensor (Front Left Side)	
S25	Shoulder Belt Anchor Motor and Position Sensor RH		U 3	Ultrasonic Sensor (Front Left)	
			U 4	Ultrasonic Sensor (Front Right Center)	
S26	Shoulder Belt Anchor Motor LH	82824-50130	U 5	Ultrasonic Sensor (Front Right Side)	
S27	Shoulder Belt Anchor Motor RH		U 6	Ultrasonic Sensor (Front Right)	
S28	Side Airbag Sensor Front LH	90980-11857	U 7	Unlock Warning SW (w/o Smart Key System)	90980-11909
S29	Side Airbag Sensor Front RH			Unlock Warning SW (w/ Smart Key System)	90980-10795
S30	Side Airbag Sensor Rear LH		U 8	Ultrasonic Sensor (Rear Left Center)	90980-11246
S31	Side Airbag Sensor Rear RH		U 9	Ultrasonic Sensor (Rear Left)	
S32	Stereo Component Amplifier	90980-10803	U10	Ultrasonic Sensor (Rear Right Center)	
S33	Stereo Component Amplifier	90980-11877	U11	Ultrasonic Sensor (Rear Right)	

Note: Not all of the above part numbers of the connector are established for the supply.

Nota: Toutes les références du connecteur ne sont pas définies pour la fourniture.

Code	Part Name	Part Number	Code	Part Name	Part Number
V 1	Variable Motor	90980-11194	V10	Vibration Seat ECU LH	90980-10803
V 2	Variable Resistor	90980-10902	V11	Vibration Seat ECU RH	
V 3	VSV (ACIS)	90980-11156	V12	Vibrator LH	90980-10908
V 4	VSV (EVAP)		V13	Vibrator RH	
V 5	VVT Sensor LH	90980-10947	W 1	Washer Level Sensor	90980-11068
V 6	VVT Sensor RH		W 2	Washer Motor	90980-10981
V 7	VSC Warning Buzzer	90980-10906	W 3	Woofer	90980-10795
V 8	Vanity Light LH	90980-11369	Y 1	Yaw Rate Sensor	90980-12080
V 9	Vanity Light RH				

*Nota : No todos los números de las partes del conector indicados arriba están dispuestos para el suministro.*

Anmerkung: Nicht alle der obenerwähnten Teile-Nummern der Stecker werden für die Lieferung etabliert.