

REPLACEMENT

REPLACE REQUIREMENTS

In the following cases, replace the seat belt pretensioner.

- If the seat belt pretensioner has been activated.
- If the seat belt pretensioner has been found to be faulty in troubleshooting.
- If the rear seat outer belt has been found to be faulty during checking Items 1-(b) or 2-(b) (See page BO-207).
- If the rear seat outer belt has been dropped.

CAUTION:

For removal and installation of the seat belt pretensioner, see page BO-204 and BO-215.

Be sure to follow the correct procedure.