

SYSTEM DESCRIPTION

1. GENERAL

The rear window defogger system's thin heater wires are attached to the inside of the rear window and defog the window surface quickly. The indicator lamp illuminates while the system is operating. The system automatically turns off after approximately 15 minutes.

2. FUNCTION OF MAIN COMPONENT

| Component | Outline |
|----------------------|---|
| DEFOG Relay | Receives rear defogger activation request signals from A/C control assembly and supplies power to rear window defogger. |
| Rear Window Defogger | Recives power from DEFOG relay and heats defogger wire. |

3. DESCRIPTION

The LS430 has the rear defogger system with following function.

| Function | Outline |
|--------------------------------|--|
| Defogs the rear window surface | Receives rear defogger activation request signals from A/C control assembly and supplies power to rear window defogger. Recives power from DEFOG relay and heats defogger wire. |