

PRECAUTION

CAUTION:

- Check that the battery cables are connected to the correct terminals.
- Disconnect the battery cables when the battery is given a quick charge.
- Do not perform tests with a high voltage insulation resistance tester.
- Never disconnect the battery while the engine is running.
- Check that the charging cable is tightened on terminal B of the generator and the fuse box.
- Do not check whether or not the generator generates when connecting terminal F to the other terminals.