

REAR BRAKE PAD COMPONENTS

BROCM-07

Right Wheel:

Pad Wear Indicator Assembly

Bleeder Plug Cap

Clamp



Clip

Inner Pad

Left Wheel:

Anti-squeal Shim

Inner Anti-squeal Shim

Inner Pad

Clip

Anti-rattle Spring

Pin

Outer Pad

Anti-squeal Shim

Inner Anti-squeal Shim

← Disc brake grease
◆ Non-reusable part

F13191