


## CIRCUIT DESCRIPTION

The position sensor sends pulses to the ECU in proportion to the amount of seat movement. The ECU records the number of pulses relative to a previously recorded seat position and uses this data to return the seat to that position.

## WIRING DIAGRAM



INSPECTION PROCEDURE

1 PERFORM ACTIVE TEST USING INTELLIGENT TESTER

- (a) Connect the intelligent tester II to the DLC3.
- (b) Turn the ignition switch ON and push the intelligent tester II main switch ON.
- (c) Select the item below in the ACTIVE TEST and then check that the rear power seat operates.

Rear LH seat ECU:

| Item     | Test Details                                                          | Diagnostic |
|----------|-----------------------------------------------------------------------|------------|
| Headrest | Test detail: Headrest operation UP/DOWN<br>Vehicle condition: Stopped | -          |

OK:  
The motor operates normally.

NG Go to step 2

OK


Go to step 4

2 INSPECT POWER SEAT MOTOR (See page 05-2434)

NG REPLACE POWER SEAT MOTOR

OK

3 CHECK WIRE HARNESS (REAR LH SEAT ECU - POWER SEAT MOTOR AND BODY GROUND)



- (a) Disconnect the R27 ECU and P48 motor connectors.
- (b) Measure the resistance of the wire harness side connectors.

Standard:

| Tester Connection            | Specified Condition |
|------------------------------|---------------------|
| R27-25 (HDWN) - P48-1 (DOWN) | Below 1 Ω           |
| R27-13 (HUP) - P48-5 (UP)    | Below 1 Ω           |
| R27-14 (GND) - Body ground   | Below 1 Ω           |

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

**4 READ VALUE OF INTELLIGENT TESTER**

- (a) Connect the intelligent tester to the DLC3.
- (b) Turn the ignition switch ON and press the intelligent tester main switch ON.
- (c) Select the items below in the DATA LIST, and read the displays on the intelligent tester.
- (d) Watch the intelligent tester screen while adjusting the seat with the power seat control switches. Check that the position sensor value changes.
- (e) Watch the intelligent tester screen while adjusting the seat with the power seat control switches. Check that the motor status changes from STANDBY to MOVING.

HINT:

When the seat is at an extreme position (for example, seat back position fully forward or sliding position fully rearward) and the power seat control switch is held down, the motor status should read LOCK. When the switch is released, the motor status should change to STANDBY.

**Rear LH seat ECU:**

| Item         | Measurement Item/<br>Display (Range)              | Normal Condition                                                           |
|--------------|---------------------------------------------------|----------------------------------------------------------------------------|
| Headrest Pos | Rear headrest position/<br>MIN: -16384 MAX: 49152 | Within range from -16384 to 49152                                          |
| Motor Status | Motor status/<br>STANDBY or MOVING or LOCK        | STANDBY: motor is idle<br>MOVING: motor is moving<br>LOCK: motor is locked |

OK:

Position sensor values should vary within the minimum and maximum values shown in the chart above.

For the tester's motor status item, the display should change between STANDBY, MOVING and LOCK according to the chart above.

NG

Go to step 5

OK

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2340)**

5

CHECK WIRE HARNESS (REAR LH SEAT ECU - POSITION SENSOR AND BODY GROUND)

Wire Harness Side

R27  
Rear LH Seat ECU

PVC2      SSRH

P48  
Power Seat Motor  
and Position Sensor

SSRV      GND      PVCC

Y

B74403

- (a)
- Disconnect the R27 ECU and P48 sensor connectors.
- (b)
- Measure the resistance of the wire harness side connectors.

Standard:

| Tester Connection            | Specified Condition |
|------------------------------|---------------------|
| R27-22 (SSRH) - P48-2 (SSRV) | Below 1 Ω           |
| R27-17 (PVC2) - P48-4 (PVCC) | Below 1 Ω           |
| P48-3 (GND) - Body ground    | Below 1 Ω           |

NG

REPAIR OR REPLACE HARNESS AND CONNECTOR

OK

6

CHECK REAR LH SEAT ECU (SENSOR POWER SOURCE VOLTAGE)

P48  
Power Seat Motor  
and Position Sensor

GND      PVCC

Y

B74318

- (a)
- Disconnect P48 sensor connector.
- (b)
- Turn the ignition switch ON.
- (c)
- Measure the voltage of the ECU connector.

Standard:


| Tester Connection          | Specified Condition |
|----------------------------|---------------------|
| P48-4 (PVCC) - P48-3 (GND) | 8 V                 |

NG

REPLACE REAR LH SEAT ECU

OK

7 CHECK POSITION SENSOR



- (a) Turn the Ignition switch ON.  
(b) Measure the voltage of the ECU connector.

Standard:

| Tester Connection            | Specified Condition                |
|------------------------------|------------------------------------|
| R27-22 (SSRH) - R27-14 (GND) | Varies between 0 V and approx. 8 V |

HINT:

Raise and lower the headrest LH and check that the voltage readings vary within the "specified condition" shown in the chart above.

NG

REPLACE POWER HEADREST ADJUSTER LH

OK

PROCEED TO NEXT CIRCUIT INSPECTION SHOWN ON PROBLEM SYMPTOMS TABLE (See page 05-2340)