

WIPER SIGNAL CIRCUIT

CIRCUIT DESCRIPTION

When the cruise control ECU (distance control ECU) detects that the wipers are operating, the dynamic radar cruise control system will be cancelled.

HINT:

A wiper switch signal is sent to the distance control ECU via the CAN and BEAN. If there are any malfunctions in this circuit, check for DTCs in the CAN communication and multiplex communication systems.

When the wiper switch is set to in the LO or HI, the dynamic radar cruise control is automatically cancelled and enters standby mode. When set to INT (intermittent operation), the radar cruise control is not cancelled.

INSPECTION PROCEDURE

1	INSPECT WIPER AND WASHER SYSTEM (See Pub. No. RM1049E, page 66-2)
---	--

OK: Wiper function is normal.

NG

**Go to WIPER AND WASHER SYSTEM
(See Pub. No. RM1049E, page 05-1578)**

OK

**PROCEED TO NEXT CIRCUIT INSPECTION SHOWN IN PROBLEM SYMPTOMS TABLE
(See page 05-20)**